


XPad v2.3

Keyboard Mode



XInput Mode





The controllers could connect to PC via USB cable or Bluetooth, it supports 4 controllers at most.

How to power on when the controllers are via Bluetooth connection:

FC30/NES30/SFC30/SNES30/ZERO: START

FC30 Pro/NES30 Pro: POWER

FC30 ARCADE JOYSTICK: HOME



Choose Keyboard Mode



Choose XInput Mode



On XInput Mode, Button A swaps with Button B, Button X swaps with button Y



On XInput Mode, Joystick (X/Y) swaps with Hat Switch



Power Mode: How to power on for each controller when in Bluetooth connection.

Help: go to the official website: <http://www.8bitdo.com/>




On Keyboard Mode, clean button mapping




On Keyboard Mode, load button mapping



On Keyboard Mode, save button mapping



Left Joystick



Right Joystick